Mandis shop

Bluesky REMCON1521

Original	Replacement
Power	Power
Open/Close	Eject
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Info	Info
Clear	Shift + Exit
Camera	Options
Menu	Menu

Original	Replacement
Title	Guide
Exit	Exit
<<	<<
>>	>>
Zoom	Shift + Eject
Up	Up
Right	Right
Down	Down
Left	Left
OK	Ok
>>I	>>I
I <<	I <<
Stop	Stop
Play	Play
Pause	Pause
Lock	Pre Ch

https://al-remote.online/en/1589-801-replacement-remote-control-for-Bluesky-REMCON1521.html