Original		Replacement	
POWER	Power		Power
INFO	[≡i] / Info	DISPLAY INFO	Info
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
SOURCE	[≡?] / Source	TIMER AV	AV
AUDIO	(OI / II / Audio	SOUND DUAL	Dual
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit

Original		Replacement	
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ENTER	Enter	OK	Ok
CH+	CH+	+ CH	Ch +
CH-	CH-	CH −	Ch -
INDEX	Index	HOME SMART	Smart
LIST	List	DISC NAV LIST	List
VOL+	Vol +	+ VOL	Vol +
VOL-	Vol -	VOL −	Vol -
♥	♥	FAV PRE-CH	Pre Ch
SLEEP	Sleep	PROG SLEEP	Sleep
EPG	EPG	-/-- GUIDE	Guide
	Back	RETURN BACK	Back
	Red	A	Red
	Green	B	Green

Original		Replacement		Original	Replacement
	Yellow	C	Yellow		
	Blue	D	Blue		
	<<	<<	<<		
	>>	>>	>>		
	I <<	I <<	I <<		
	>>I	>>I	>>I		
	[≡] / Text	REPEAT TEXT	Text		
	Play/Pause	PLAY MODE ▶	Play		
STILL	[≡+] / Still	PICTURE FORMAT	Format		
STILL	Stop	■	Stop		
RADIO	Radio	SEARCH TV/R	TV/R		
	[≡♦*/ [+]	ECO 3D	3D		
	[≡x]	SETTINGS OPT	Options		
SUBTITLE	[≡o] / Subtitle	AD SUBT	Subt		
DMP	DMP	APP MEDIA	Media		
	Rec	REC MODE	Rec		