Mandis shop

RC- 858

Original		Replacement		Original	Replacement
POWER	Power		Power		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
	Track >>I	PRESET+	>>I / Preset+		
	Function Up	CH PAGE +	CH+ / Page+		
UP	Volume Up	VOL +	Vol +		
TRACK	I<< Track	PRESET-	I<< / Preset-		
FUNCTION	Function Down	CH PAGE −	CH- / Page-		
DOWN VOLUME	Volume Down	VOL −	Vol -		
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze		
STOP	Stop	HOLD	Stop / Hold		
PLAY	Play	SLOW	Play / Slow		

https://al-remote.online/en/Denon/1353362-replacement-remote-control-for-Denon-RC858/1390305/#