Original		Replacement	
	Power		Power
	Mute		Mute / Dimmer
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	<<[≡o]		<< / Tune-
	>>[≡?]		>> / Tune+
	I<<[≡+]		I<< / Preset-
	>>I[≡..]		>>I / Preset+
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	[≡i]		Smart / List
	Text		Text / Goto
	Subtitle		Subtitle / EQ
	Freeze		Shift + Pause / Step / Freeze

Original		Replacement	
	Info		Info / Angle
	[I]/Menu		Menu / Home
	Up		Up
	Source		AV / Input / RDS
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	EPG		Guide / EPG / -/--
	Exit		Exit / Cancel / Clear
	Vol+		Vol+
	FAV		Fav / Marker / PC
	CH+		CH+ / Page+
	Vol-		Vol-
	REP/Rec		Rec / Rec Mode
	CH-		CH- / Page-
	1		1

Original		Replacement		Original	Replacement
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
0	0	HDMI - SAT 0	0		
RECALL	Recall	RETURN BACK	Back / Return		

Original	Replacement	Original	Replacement
Power	Power	TXT/MIX	Text / Goto
Mute	Mute / Dimmer	Menu	Menu / Home
Play	Play / Slow	Up	Up
Pause	Pause / Step / Freeze	Info	Info / Angle
Stop	Stop / Hold	Left	Left
Rec	Rec / Rec Mode	Enter	OK
<<</Hold	<< / Tune-	Right	Right
>>/Index	>> / Tune+	Cancel	Exit / Cancel / Clear
I<<	I<< / Preset-	Down	Down
>>I	>>I / Preset+	Back	Back / Return
Nicam/A2	Audio / Lang I/II	Vol+	Vol+
Subtitle	Subtitle / EQ	List	Smart / List
Subpage	Eject / Surround	CH+	CH+ / Page+
Size	Zoom / Size	Vol-	Vol-
Sleep	Sleep / Timer	Mode	Display / Media
DTV/Radio	TV/Radio /	CH-	CH- / Page-
Reveal	D.Menu / Top Menu	1	1

Original	Replacement
2	DVD 2
3	CD - STB 3
4	VIDEO 4
5	TAPE 5
6	TUNER 6
7	AUX - HDD 7
8	USB 8
9	BLUETOOTH 9
EPG	-/-- GUIDE EPG
0	HDMI - SAT 0
FAV	PC FAV MARKER
Red	NETFLIX SEARCH
Green	APP REPEAT
Yellow	YouTube REPEAT A-B
Blue	Prime Video RANDOM
<<</Hold	SHIFT + HOLD
FAV-	SHIFT +

Original	Replacement
FAV+	SHIFT + Shift + Right
-/--	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--

Original	Replacement	Original	Replacement
Power	Power	Up	Up
Mute	Mute / Dimmer	Info	Info / Angle
Play	Play / Slow	Left	Left
Pause	Pause / Step / Freeze	Ok	OK
Stop	Stop / Hold	Right	Right
Rec	Rec / Rec Mode	Exit	Exit / Cancel / Clear
<<[Timer]	<< / Tune-	Down	Down
>>/[≡?]	>> / Tune+	Recall	Back / Return
I<<[≡↕]	I<< / Preset-	Vol+	Vol+
>>I/[≡...]	>>I / Preset+	[≡i]	Smart / List
Audio	Audio / Lang I/II	Ch+	CH+ / Page+
Subtitle	Subtitle / EQ	Vol-	Vol-
I<<[≡↕]	Zoom / Size	Ch-	CH- / Page-
<<[Timer]	Sleep / Timer	1	1
Text	Text / Goto	2	2
Source/Av	AV / Input / RDS	3	3
[II]	Menu / Home	4	4

Original	Replacement	Original	Replacement
5	TAPE 5		
6	TUNER 6		
7	AUX - HDD 7		
8	USB 8		
9	BLUETOOTH 9		
Epg	-/-- GUIDE EPG		
0	HDMI - SAT 0		
Fav	PC FAV MARKER		
Red	NETFLIX SEARCH		
Green	APP REPEAT		
Yellow	YouTube REPEAT A-B		
Blue	Prime Video RANDOM		
Freeze	SHIFT + STEP - FREEZE		