Original		Replacement	
	Power		Power
	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
V+	Vol +	+ VOL	Vol +
V-	Vol -	VOL –	Vol -
P+	PR+	+ CH	Ch +
P-	PR-	CH –	Ch -
EXIT	Exit	CLEAR EXIT	Exit
BACK	Back	RETURN BACK	Back
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
INFO	Info	DISPLAY INFO	Info

Original		Replacement	
MENU	Menu	TOP MENU MENU	Menu
	Mute	MUTE	Mute
SOURCE	Source	TIMER AV	AV
SWAP	Swap	FAV PRE-CH	Pre Ch
0	0	0	0
1	1	1	1
2 ABC	2	2	2
3 DEF	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
6 MNO	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
9 WXYZ	9	9	9
EPG	EPG	-/-- GUIDE	Guide
TEXT	Text	REPEAT TEXT	Text
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch

Original		Replacement		Original	Replacement
SLEEP	Sleep	PROG SLEEP	Sleep		
SUBTITLE	Subtitle	AD SUBT	Subt		
LANG	Lang	SOUND DUAL	Dual		
SCREEN	Screen	PICTURE FORMAT	Format		
PRESETS	Presets	ZOOM ⏏	Eject		
INTERNET	Internet	HOME SMART	Smart		
MULTIMEDIA	Multimedia	APP MEDIA	Media		
▶	Play	PLAY MODE ▶	Play		
MY BUTTON 1	My Button1	DISC NAV LIST	List		
MY BUTTON 2	My Button2	E-MANUAL D.MENU	D. Menu		
●	Rec	REC MODE ●	Rec		
❚❚	Pause	❚❚	Pause		
■	Stop	■	Stop		
▶▶	>>	≫	>>		
◀◀	<<	≪	<<		
▶▶❙	>>❙	≫❙	>>❙		
❙◀◀	❙ <<	❙≪	❙ <<		