Mandis shop

RC-1000C

| Original | | Replacement | |
|---|---|---|---|
| | Line 1 | | Power |
| | Line2 | DIMMER MUTE | Mute / Dimmer |
| BALANCED | Balanced | SLOW | Play / Slow |
| | Tape1 | STEP-FREEZE | Pause / Step / Freeze |
| | Tape 2 | HOLD | Stop / Hold |
| PHONO | Phono | REC MODE | Rec / Rec Mode |
| SOURCE DIRECT ON/OFF | Source Direct On/Off | TUNE- | << / Tune- |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

https://all-remotes.online/en/Kenwood/1066924-93672-replacement-remote-control-for-Kenwood-RC-1000C.html