Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	AUX	5	5
MEDIA PLAYER	Media Player	6	6
USB	USB	7	7
TV AUDIO	TV Audio	8	8
TUNER	Tuner	9	9
	.:l:.	-/-- GUIDE	Guide
Bluetooth	Bluetooth	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
MUTE	Mute	MUTE	Mute
CH / PAGE	CH/Page+	+ CH	Ch +
CH / PAGE	CH/Page-	CH –	Ch -

Original		Replacement	
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL –	Vol -
ECO	Eco	ECO 3D	3D
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
ENTER	Enter	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause
TUNE –	I<</Tune-	I<<	I<<
TUNE +	>>I/Tune+	>>I	>>I
MOVIE	Green/Movie	B	Green

Original		Replacement	
MUSIC	Red/ Music	A	Red
GAME	Blue/ Game	D	Blue
PURE	Yellow/ Pure	C	Yellow
1	Quick Select 1	E-MANUAL D.MENU	D. Menu
2	Quick Select 2	REPEAT TEXT	Text
3	Quick Select 3	ZOOM	Eject
4	Quick Select 4	TIMER AV	AV

Original	Replacement

Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	AUX	5	5
MEDIA PLAYER	Media Player	6	6
USB	USB	7	7
TV AUDIO	TV Audio	8	8
TUNER	Tuner	9	9
	.:l:.	-/-- GUIDE	Guide
Bluetooth	Bluetooth	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
CH / PAGE	CH/Page+	+ CH	Ch +
CH / PAGE	CH/Page-	CH –	Ch -
VOLUME	Vol +	+ VOL	Vol +

Original		Replacement	
VOLUME	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
BACK	Back	RETURN BACK	Back
ENTER	Enter	OK	Ok
	Up		Up
	Down		Down
	Left		Left
	Right		Right
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause
TUNE – ⏮	I<</Tune-	I<<	I<<
TUNE + ⏭	>>I/Tune+	>>I	>>I
1	Quick Select 1	E-MANUAL D.MENU	D. Menu
4	Quick Select 4	TIMER AV	AV
3	Quick Select 3	ZOOM ⏏	Eject
2	Quick Select 2	REPEAT TEXT	Text