| Original | Replacement |
|---|---|
| On / Standby | Power |
| Input Selector V | 1 |
| Input Selector V | 2 |
| Input Selector V | 3 |
| Input Selector Multi CH | 5 |
| Input Selector | 6 |
| Input Selector | 7 |
| Input Selector Tuner | 8 |
| Input Selector C | 9 |
| Dimmer | 0 |
| Sleep | Sleep / Timer |
| Guide/Top | Menu / Home |
| Muting | Mute / Dimmer |
| Return | Back / Return |
| Setup | Eject / Surround |
| Enter | OK |
| Up | Up |

| Original | Replacement |
|---|---|
| Down | Down |
| Right | Right |
| Left | Left |
| Play | Play / Slow |
| Rev. Play | Pause / Step / Freeze |
| Stop | Stop / Hold |
| << | >> / Tune+ |
| >> | I<< / Preset- |
| I<< | << / Tune- |
| >>I | >>I / Preset+ |
| Listening Mode Stereo | Red / Netflix / Search |
| Listening Mode Surround | Green / APP / Repeat |
| Listening Mode < | Yellow / YouTube / Repeat |
| Listening Mode > | Blue / Prime Video / Random |
| Test Tone/Audio | Audio / Lang I/II |
| CH Sel/Subtitl | Subtitle / EQ |
| Level -/Random | TV/Radio / Program |

| Original | | Replacement | |
|---|---|---|---|
| REPEAT LEVEL+ | Level +/ Repeat | SIZE ZOOM | Zoom / Size |
| DISPLAY | Display | ANGLE INFO | Info / Angle |
| L NIGHT DVD | L. Night | LIST SMART | Smart / List |
| CINE FLTR HDD | Cine FLTR | MEDIA DISPLAY | Display / Media |
| INPUT | Input Tv | SHIFT + RDS AV INPUT | Shift + AV / Input / RDS |
| CH DISC ALBUM + | CH/ Disc/ Album | CH + PAGE | CH+ / Page+ |
| CH DISC ALBUM − | CH/ Disc/ Album- | CH PAGE − | CH- / Page- |
| VOL ▲ | Vol + | + VOL | Vol + |
| VOL ▼ | Vol - | VOL − | Vol - |
| I/⏻ | Power Tv/ Standby | SHIFT + ⏻ | Shift + Power |
| VOL ▲ | Vol + Tv | SHIFT + + VOL | Shift + Vol + |
| VOL ▼ | Vol - Tv | SHIFT + VOL − | Shift + Vol - |
| 1 V1 | 1 Tv | SHIFT + TV 1 | Shift + 1 |
| 2 V2 | 2 Tv | SHIFT + DVD 2 | Shift + 2 |
| 3 V3 | 3 Tv | SHIFT + CD - STB 3 | Shift + 3 |
| 4 V4 | 4 Tv | SHIFT + VIDEO 4 | Shift + 4 |
| 5 MULTI CH | 5 Tv | SHIFT + TAPE 5 | Shift + 5 |

| Original | | Replacement | |
|---|---|---|---|
| 6 DVD | 6 Tv | SHIFT + TUNER 6 | Shift + 6 |
| 7 TAPE | 7 Tv | SHIFT + AUX - HDD 7 | Shift + 7 |
| 8 TUNER | 8 Tv | SHIFT + USB 8 | Shift + 8 |
| 9 CD | 9 Tv | SHIFT + BLUETOOTH 9 | Shift + 9 |
| 0 DIMMER | 0 Tv | SHIFT + HDMI - SAT 0 | Shift + 0 |
| +10 | +10 Tv | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| PREVIOUS MENU MUTING | Muting/ Previous Menu Tv | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer |
| ENTER | Enter Tv | SHIFT + OK | Shift + OK |
| PLAYLIST/CAT ► | Right Tv | SHIFT + ► | Shift + Right |
| ◄ PLAYLIST/CAT | Left Tv | SHIFT + ◄ | Shift + Left |
| SETUP | Setup Tv | TOP MENU D.MENU | D. Menu / Top |
| ▲ | Up Tv | SHIFT + ▲ | Shift + Up |
| ▼ | Down Tv | SHIFT + ▼ | Shift + Down |

| Original | | Replacement | |
|---|---|---|---|
| ON/STANDBY | Power | | Power |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| VCR | VCR | SHIFT + VIDEO 4 | Shift + 4 |
| +10 | +10/10/-/-- | GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0/11 | HDMI-SAT 0 | 0 |
| CLR | CLR | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| GUIDE TOP MENU | Top Menu | TOP MENU D.MENU | D. Menu / Top |
| | Up | | Up |
| PREVIOUS MENU MUTING | Previous Menu/Muting | HOME MENU | Menu / Home |

| Original | | Replacement | |
|---|---|---|---|
| PREVIOUS MENU MUTING | Previous Menu/Muting | DIMMER MUTE | Mute / Dimmer |
| PLAYLIST/CAT | Left/Playlist/Ca | | Left |
| ENTER | Enter | OK | OK |
| PLAYLIST/CAT | Right/Playlist/C | | Right |
| RETURN | Return | RETURN BACK | Back / Return |
| | Down | | Down |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Play | SLOW | Play / Slow |
| | Stop | HOLD | Stop / Hold |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| | I << | PRESET- | I << / Preset- |
| | >>I | PRESET+ | >>I / Preset+ |
| STEREO | Stereo | TITLE SOUND | Sound / Title |
| SURROUND | Surround | SURROUND | Eject / Surround |
| | < Listening Mode | SHIFT + PRESET- | Shift + I << / Preset- |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Listening Mode > | SHIFT + PRESET+ | | |
| Audio | LANG I/II AUDIO | | |
| Subtitle | EQ SUBTITLE | | |
| Random | Prime Video RANDOM | | |
| Repeat | APP REPEAT | | |
| Display | MEDIA DISPLAY | | |
| Play Mode VCR | FORMAT PICTURE | | |
| DVD | SHIFT + DVD 2 | | |
| HDD | SHIFT + AUX - HDD 7 | | |

| Original | Replacement |
|---|---|
| On / Standby | Power |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| +10/10/-/-- | Guide / EPG / -/-- |
| 0/11 | 0 |
| 12 | Fav / Marker / PC |
| Disc+ | CH+ / Page+ |
| Vol + | Vol + |
| Disc- | CH- / Page- |
| Vol - | Vol - |

| Original | Replacement |
|---|---|
| Pause | Pause / Step / Freeze |
| Play | Play / Slow |
| Stop | Stop / Hold |
| << | << / Tune- |
| >> | >> / Tune+ |
| I << | I << / Preset- |
| >>I | >>I / Preset+ |
| Stereo | Audio / Lang I/II |
| Surround | Eject / Surround |
| < Listening Mode | Shift + I << / Preset- |
| Listening Mode > | Shift + >>I / Preset+ |
| Random | Blue / Prime Video / Random |
| Repeat | Green / APP / Repeat |
| Display | Display / Media |

| Original | | Replacement | |
|---|---|---|---|
| ON/STANDBY | Power | | Power |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| +10 | +10/10/-/-- | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0/11 | HDMI-SAT 0 | 0 |
| CH DISC ALBUM + | CH+ | CH PAGE + | CH+ / Page+ |
| CH DISC ALBUM − | CH- | CH PAGE − | CH- / Page- |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Play | SLOW | Play / Slow |
| | Stop | HOLD | Stop / Hold |

| Original | | Replacement | |
|---|---|---|---|
| | << | TUNE- | << / Tune- |
| STEREO | Stereo | LANG I/II AUDIO | Audio / Lang I/II |
| SURROUND | Surround | SURROUND | Eject / Surround |
| | < Listening Mode | SHIFT + PRESET- | Shift + I<< / Preset- |
| | Listening Mode > | SHIFT + PRESET+ | Shift + >>I / Preset+ |
| PLAY MODE VCR | Play Mode | TOP MENU D.MENU | D.Menu / Top |
| L NIGHT DVD | L. Night | TIMER SLEEP | Sleep / Timer |