Original		Replacement	
	Power MD		Power
	Direct Tuning		Text
	Dimmer		Pre Ch
	TV		TV/R
	CD		Yellow
	DVD		Blue
	Tuner/Band		Green
	Tape		Red
	VCR		Smart
	MD		Media
	Vol +		Vol +
	Vol -		Vol -
	Muting		Mute
	Stop MD		Stop
	Play MD		Play
	<</I<< MD		<<
	>>/>>I MD		>>

Original		Replacement	
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Menu		D. Menu
	Display		Info
	Top Menu/Disc/Deck		Menu
	1 MD		1
	2 MD		2
	3 MD		3
	4 MD		4
	5 MD		5
	6 MD		6
	7 MD		7
	8 MD		8
	9 MD		9

Original		Replacement	
0	0 MD	0	0
≥10/-/--	>10/-/-- MD	-/-- GUIDE	Guide
TV/AV	Tv/AV	TIMER AV	AV
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH −	Ch -
	Power TV	SHIFT +	Shift + Power
VOL ^	Tv Vol Up	SHIFT + + VOL	Shift + Vol +
TV v	Tv Vol Down	SHIFT + VOL −	Shift + Vol -
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3

Original		Replacement	
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
0	0 Tv	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/-- Tv	SHIFT + -/-- GUIDE	Shift + Guide

Original		Replacement	
	Power DVD		Power
TV	TV	SEARCH TV/R	TV/R
VCR	VCR	HOME SMART	Smart
TUNER/ BAND	Tuner/Band	B	Green
TAPE	Tape	A	Red
MD	MD	APP MEDIA	Media
CD	CD	C	Yellow
DVD	DVD	D	Blue
	Play DVD	PLAY MODE	Play
	I<</<< DVD		<<
	Stop DVD		Stop
	>>/>>I DVD		>>
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu
DISPLAY	Display	DISPLAY INFO	Info
MENU	Menu	E-MANUAL D.MENU	D. Menu
	Up		Up
	Down		Down

Original		Replacement	
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH -	Ch -
1	1 DVD	1	1
2	2 DVD	2	2
3	3 DVD	3	3
4	4 DVD	4	4
5	5 DVD	5	5
6	6 DVD	6	6

Original	Replacement	Original	Replacement
7 DVD	7		
8 DVD	8		
9 DVD	9		
0 DVD	0		
>10/ - / - - DVD	Guide		
Vol +	Vol +		
Vol -	Vol -		
Muting	Mute		

Original		Replacement	
	Power CD		Power
TV	TV	SEARCH TV/R	TV/R
VCR	VCR	HOME SMART	Smart
CD	CD	C	Yellow
DVD	DVD	D	Blue
TAPE	Tape	A	Red
MD	MD	APP MEDIA	Media
TUNER/ BAND	Tuner/Band	B	Green
	Stop CD		Stop
I<</<< CD		<<	<<
>>/>>I CD		>>	>>
	Play CD	PLAY MODE	Play
MENU	Menu	E-MANUAL D.MENU	D. Menu
DISPLAY	Display	DISPLAY INFO	Info
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu
	Up		Up
	Down		Down

Original		Replacement	
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH -	Ch -
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
MUTING	Muting	MUTE	Mute
	Power Tape	SHIFT +	Shift + Power
	Stop Tape	SHIFT +	Shift + Stop
	Play Tape	SHIFT + PLAY MODE	Shift + Play

Original		Replacement		Original	Replacement
I <</ << Tape		SHIFT + <<	Shift + <<		
>>/ >>I Tape		SHIFT + >>	Shift + >>		
Top Menu/ Disc/ Deck		SHIFT + TOP MENU / MENU	Shift + Menu		
1 CD- Tape		1	1		
2 CD- Tape		2	2		
3 CD- Tape		3	3		
4 CD- Tape		4	4		
5 CD- Tape		5	5		
6 CD- Tape		6	6		
7 CD- Tape		7	7		
8 CD- Tape		8	8		
9 CD- Tape		9	9		
0 CD- Tape		0	0		
>10/ - / - - CD- Tape		GUIDE	Guide		
Direct Tuning/ Disc Ente		REPEAT / TEXT	Text		

Original		Replacement	
	Power VCR		Power
DIMMER	Dimmer	FAV PRE-CH	Pre Ch
VCR	VCR	HOME SMART	Smart
TAPE	Tape	A	Red
TV	TV	SEARCH TV/R	TV/R
CD	CD	C	Yellow
DVD	DVD	D	Blue
TUNER/ BAND	Tuner/Band	B	Green
MD	MD	APP MEDIA	Media
	Stop		Stop
	I<</<<		<<
	>>/>>I		>>
	Play	PLAY MODE	Play
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4

Original		Replacement	
5	5 VCR	5	5
6	6 VCR	6	6
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
≥10/-/--	>10/-/-- VCR	-/-- GUIDE	Guide
DIRECT TUNING DISC ENTER	Direct Tuning/Disc Ente	REPEAT TEXT	Text
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
MUTING	Muting	MUTE	Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu

Original		Replacement	
DISPLAY	Display	DISPLAY INFO	Info
MENU	Menu	E-MANUAL D.MENU	D. Menu
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH -	Ch -
Power	Tuner / Band	SHIFT + Power	Shift + Power
1	1 Tuner / Band	SHIFT + 1	Shift + 1
2	2 Tuner / Band	SHIFT + 2	Shift + 2
3	3 Tuner / Band	SHIFT + 3	Shift + 3
4	4 Tuner / Band	SHIFT + 4	Shift + 4
5	5 Tuner / Band	SHIFT + 5	Shift + 5
6	6 Tuner / Band	SHIFT + 6	Shift + 6

Original		Replacement	
7	7 Tuner / Band	SHIFT + 7	Shift + 7
8	8 Tuner / Band	SHIFT + 8	Shift + 8
9	9 Tuner / Band	SHIFT + 9	Shift + 9
0	0 Tuner / Band	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/--	SHIFT + -/-- GUIDE	Shift + Guide