Original		Replacement	
	Power		Power
	Open/Close		Eject / Surround
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Cancel		Shift + Exit / Cancel / Clear
	Audio		Audio / Lang I/II
	Receiver Vol +		Vol +
	Receiver Vol -		Vol -
	Receiver Mute		Mute / Dimmer

Original		Replacement	
	Vieta Cast		Smart / List
	I<< Skip		I<< / Preset-
	Skip >>I		>>I / Preset+
	<< Slow/Search		<< / Tune-
	Slow/Search >>		>> / Tune+
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Status		Text / Goto
	Exit		Exit / Cancel / Clear
	Option		Shift + Setup / OPT / Tools
	Return		Back / Return
	Top Menu/Direct Navigator		D.Menu / Top
	Pop-Up Menu		Shift + Menu /
	Function Menu		Menu / Home
	Up		Up
	Down		Down

Original		Replacement		Original	Replacement
	Right		Right		
	Left		Left		
OK	OK	OK	OK		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /		
PIP	PIP	FORMAT PICTURE	Picture / Format		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		
DRIVE SELECT	Select Drive	RDS AV INPUT	AV / Input / RDS		
	Power Tv	SHIFT +	Shift + Power		
AV	AV Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS		
VOL +	TV Vol +	SHIFT + VOL +	Shift + Vol +		
VOL -	TV Vol -	SHIFT + VOL -	Shift + Vol -		
CH	TV CH+	CH PAGE +	CH+ / Page+		
CH	TV CH-	CH PAGE -	CH- / Page-		