Original		Replacement	
	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
SEARCH	<<	TUNE-	<< / Tune-
SEARCH	>>	TUNE+	>> / Tune+
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
SOUND CH SELECT	Sound/CH	LANG I/II AUDIO	Audio / Lang I/II
W.SRD	W.SRD	FORMAT PICTURE	Picture / Format
EXT-IN	Ext-In	SIZE ZOOM	Zoom / Size
SURROUND SLEEP	Surround/Sleep	TIMER SLEEP	Sleep / Timer
RADIO	Radio	PROGRAM TV/RADIO	TV/Radio /
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
FUNCTIONS	Functions	OPT-TOOLS SETUP	Setup / OPT /
PLAY MODE	PlayMode/Repe	GOTO TEXT	Text / Goto

Original		Replacement	
START	Start	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Left/◁II		Left
OK	OK	OK	OK
	II▷/Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
VOL	Vol +	VOL	Vol +
VOL	Vol + Tv	CH PAGE	CH+ / Page+
VOL	Vol -	VOL	Vol -
FL DISPLAY	FL. Display	MEDIA DISPLAY	Display / Media
VOL	Vol - Tv	CH PAGE	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3

Original		Replacement		Original	Replacement
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
≥10	+10	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
TV	Power Tv	SHIFT +	Shift + Power		
INPUT AV	AV Input	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS		
CANCEL	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear		
DVD	DVD	SHIFT + DVD 2	Shift + 2		