Original		Replacement	
	Power		Power
TV	TV	A	Red
DISC	DISC	B	Green
TUNER	TUNER	C	Yellow
AUX	AUX	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
MENU OSD	OSD Menu	TOP MENU MENU	Menu

Original		Replacement	
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
	I<<		I<<
	>>I		>>I
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PAUSE	Pause		Pause
	I<<		<<
	>>I		>>
SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE	Angle	HOME SMART	Smart
ZOOM	Zoom	ZOOM	Eject

Original		Replacement		Original	Replacement
SET UP	Set Up	SETTINGS OPT	Options		
REPEAT	Repeat	REPEAT TEXT	Text		
REPEAT A-B	Repeat A-B	SHIFT +	PLAY MODE ▶ Shift + Play		
SCAN	Scan	APP MEDIA	Media		
RETURN/TITLE	Return / Titl	RETURN BACK	Back		
AUDIO	Audio	SOUND DUAL	Dual		
PROG	Prog	SHIFT +	PROG SLEEP Shift + Sleep		
SLEEP	Sleep	PROG SLEEP	Sleep		
MUTE	Mute	MUTE	Mute		
SOUND	Sound	SHIFT +	SOUND DUAL Shift + Dual		
SURR	SURR	PICTURE FORMAT	Format		
TV VOL +	TV Vol +	+ CH	Ch +		
TV VOL −	TV Vol -	CH −	Ch -		

Original		Replacement	
	Power		Power
DISC	DISC	B	Green
TV	TV	A	Red
TUNER	TUNER	C	Yellow
AUX	AUX	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -

Original		Replacement	
TV VOL +	TV Vol +	CH +	Ch +
TV VOL −	TV Vol -	CH −	Ch -
⏭	>>I	⏭	>>I
⏭	>>I	»	>>
⏮	I <<	⏮	I <<
⏮	I <<	«	<<
▲	Up	▲	Up
◀	Left	◀	Left
OK	OK	OK	Ok
▶	Right	▶	Right
▼	Down	▼	Down
STOP	Stop	■	Stop

Original		Replacement	
TV	TV	A	Red
DISC	DISC	B	Green
TUNER	TUNER	C	Yellow
AUX	AUX	D	Blue
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	>>I		>>I
	>>I		>>

Original		Replacement	
	I <<		I <<
	I <<		<<
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
PROG	Prog	PROG SLEEP	Sleep
STOP	Stop		Stop

Original		Replacement	
TV	TV	A	Red
DISC	DISC	B	Green
TUNER	TUNER	C	Yellow
AUX	AUX	D	Blue
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
>>I	>>I	>>I	>>I
>>I	>>I	>>	>>

Original		Replacement	
I<<	I<<	I<<	I<<
I<<	I<<	<<	<<
Up	Up	Up	Up
Down	Down	Down	Down
OK	OK	OK	Ok
Right	Right	Right	Right
PROG	Prog	PROG SLEEP	Sleep
STOP	Stop	Stop	Stop