Original	Replacement
Mute	Mute / Dimmer
Power	Power
(↔)	Audio / Lang I/II
TV	TV/Radio /
_/	Sound / Title
[#]→	Picture / Format
[.≡]	Text / Goto
[≡+]	Shift + Stop /
[≡♦]	Shift + Zoom /
[≡x]◷	Back / Return
[≡?][+]	Sleep / Timer
1	1
2	2
3	3
[≡i]	Info / Angle
4	4
5	5

Original	Replacement
6	6
A/B	Shift + Yellow / YouTube /
7	7
8	8
9	9
Output	AV / Input / RDS
-/--	Guide / EPG / -/--
0	0
C	Exit / Cancel / Clear
IN 123	D.Menu / Top
1-/TP Off	Fav / Marker / PC
C00	Setup / OPT /
2-/TP On	Shift + Fav / Marker / PC
Vol +	Vol +
Prog+	CH+ / Page+
Vol -	Vol -
Prog-	CH- / Page-

Original	Replacement	Original	Replacement
Red	Red / Netflix / Search	Contrast-	I<< / Preset-
Green	Green / APP / Repeat	Brightness-	Shift + Left
Yellow	Yellow / YouTube / Repeat	Power Down	Shift + Power
Blue	Blue / Prime Video / Random	Prog- Down	Shift + CH- /
->	Display / Media	<<	<< / Tune-
-[<>]	Left	Play	Play / Slow
[<>]+	Right	>>	>> / Tune+
♦	Zoom / Size	Stop	Stop / Hold
(*)	Menu / Home	Pause	Pause / Step / Freeze
→←	Smart / List		
[II··]	OK		
[II··]+	Up		
[...]	Subtitle / EQ		
Contrast+	>>I / Preset+		
Brightness+	Shift + Right		
[II··]-	Down		
Prog+ Down	Shift + CH+ / Page+		

Original		Replacement	
	Power Down		Power
PROGR +	Prog+ Down	CH PAGE +	CH+ / Page+
PROGR −	Prog- Down	CH PAGE −	CH- / Page-
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Rec	REC MODE	Rec / Rec Mode
	>>	TUNE+	>> / Tune+
	Play	SLOW	Play / Slow
	<<	TUNE-	<< / Tune-

Original	Replacement

Original	Replacement	Original	Replacement
Power Down	Power		
Prog+ Down	CH+ / Page+		
Prog- Down	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		
>>	>> / Tune+		
Play	Play / Slow		
<<	<< / Tune-		

Original		Replacement		Original		Replacement	
	Power Down		Power				
PROGR	Prog+ Down	CH PAGE	CH+ / Page+				
PROGR	Prog- Down	CH PAGE	CH- / Page-				
	<<	TUNE-	<< / Tune-				
	Play	SLOW	Play / Slow				
	>>	TUNE+	>> / Tune+				
	Stop	HOLD	Stop / Hold				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
	Rec	REC MODE	Rec / Rec Mode				