Original	Replacement	Original	Replacement
Sleep	Sleep / Timer	Smart Picture	Picture / Format
Power	Power	Menu	Menu / Home
Exit	Exit / Cancel / Clear	Up	Up
Settings	Setup / OPT /	Audio	Audio / Lang I/II
Screen Swap	Smart / List	Left	Left
Guide	Guide / EPG / -/--	Right	Right
1	1	Vol +	Vol +
2	2	Down	Down
3	3	P+	CH+ / Page+
4	4	Vol -	Vol -
5	5	Mute	Mute / Dimmer
6	6	P-	CH- / Page-
7	7	Red	Red / Netflix / Search
8	8	Green	Green / APP / Repeat
9	9	Yellow	Yellow / YouTube / Repeat
Smart Sound	Sound / Title	Blue	Blue / Prime Video / Random
0	0	Text / OK	OK

Original		Replacement		Original	Replacement
OK	Text / OK	GOTO TEXT	Text / Goto		
	Timer / Size	SIZE ZOOM	Zoom / Size		
	Hold	HOLD ■	Stop / Hold		
	Mix	SHIFT + GOTO TEXT	Shift + Text /		
	Reveal	SLOW ▶	Play / Slow		
OSD	Index / OSD	MEDIA DISPLAY	Display / Media		
I-II	I-II	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		
	Format	TOP MENU D.MENU	D. Menu / Top		
P<P	P<P	RETURN BACK	Back / Return		

Original	Replacement
Sleep	Sleep / Timer
Power	Power
Screen Swap	Smart / List
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Smart Sound	Sound / Title
0	0
Smart Picture	Picture / Format
Menu	Menu / Home
Up	Up

Original	Replacement
Audio	Audio / Lang I/II
Left	Left
Right	Right
Vol +	Vol +
Down	Down
P+	CH+ / Page+
Vol -	Vol -
Mute	Mute / Dimmer
P-	CH- / Page-
<<	<< / Tune-
Stop	Stop / Hold
Play	Play / Slow
OK	OK
>>	>> / Tune+
Pause	Pause / Step / Freeze
OSD	Display / Media
I-II	Shift + Audio / Lang I/II

Original	Replacement	Original	Replacement
Format	D. Menu / Top		

Original		Replacement		Original		Replacement	
	Sleep	TIMER SLEEP	Sleep / Timer		Up		Up
	Power		Power		Audio	LANG I/II AUDIO	Audio / Lang I/II
	Screen Swap	LIST SMART	Smart / List		Left		Left
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		Right		Right
1	1	TV 1	1		Vol +	+ VOL	Vol +
2	2	DVD 2	2		Down		Down
3	3	CD - STB 3	3		P+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4		Vol -	VOL −	Vol -
5	5	TAPE 5	5		Mute	DIMMER MUTE	Mute / Dimmer
6	6	TUNER 6	6		P-	CH PAGE −	CH- / Page-
7	7	AUX - HDD 7	7		Rec	REC MODE	Rec / Rec Mode
8	8	USB 8	8		<<	TUNE-	<< / Tune-
9	9	BLUETOOTH 9	9		Stop	HOLD	Stop / Hold
SMART	Smart Sound	TITLE SOUND	Sound / Title		Play	SLOW	Play / Slow
0	0	HDMI - SAT 0	0	OK	OK	OK	OK
SMART	Smart Picture	FORMAT PICTURE	Picture / Format		Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
MENU	Menu	HOME MENU	Menu / Home		>>	TUNE+	>> / Tune+

Original	Replacement	Original	Replacement
Pause	Pause / Step / Freeze		
OSD	Display / Media		
I-II	Shift + Audio / Lang I/II		
Format	D.Menu / Top		