| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| INPUT | Input | RDS AV INPUT | AV / Input / RDS |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| P.STD | P.STD | FORMAT PICTURE | Picture / Format |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| -/-- | -/-- | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 | HDMI - SAT 0 | 0 |
| PRE-CH | Pre-CH | RETURN BACK | Back / Return |

| Original | | Replacement | |
|---|---|---|---|
| V.MENU | V.Menu | TOP MENU D.MENU | D.Menu / Top |
| MENU | Menu | HOME MENU | Menu / Home |
| VOL | Vol - | VOL | Vol- |
| P | P + | CH PAGE | CH+ / Page+ |
| VOL | Vol + | VOL | Vol+ |
| P | P - | CH PAGE | CH- / Page- |
| REW | << REW | TUNE- | << / Tune- |
| STOP | Stop | HOLD | Stop / Hold |
| PLAY | Play | SLOW | Play / Slow |
| FF | >> FF | TUNE+ | >> / Tune+ |
| REC | Rec | REC MODE | Rec / Rec Mode |
| EJECT | Eject | SURROUND | Eject / Surround |
| P/S | Pause / P/S | STEP - FREEZE | Pause / Step / Freeze |
| CRYSTAL PB | Crystal PB | LIST SMART | Smart / List |
| TRK | TRK Up | PRESET+ | >>I / Preset+ |
| TRK | TRK Up | | Up |
| INDEX | Index | ANGLE INFO | Info / Angle |

| Original | | Replacement | |
|---|---|---|---|
| MEMORY | Memory | OK | OK |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| TRK | TRK Down | | Down |
| TRK | TRK Down | PRESET- | I<< / Preset- |
| LANG.SEL | Lang Sel | LANG I/II AUDIO | Audio / Lang I/II |
| CLEAR X | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |

| Original | Replacement |
|---|---|
| | |