Original		Replacement	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
–	-	-/-- GUIDE	Guide
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
ANTENNA	Antenna	APP MEDIA	Media
CH LIST	CH List	DISC NAV LIST	List
FAV.CH	FAV. CH	SHIFT + FAV PRE-CH	Shift + Pre Ch

Original		Replacement	
SLEEP	Sleep	PROG SLEEP	Sleep
VOL +	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
CH+	CH+	+ CH	Ch +
CH-	CH-	CH –	Ch -
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
RETURN	Return	RETURN BACK	Back
INFO	Info	DISPLAY INFO	Info
CAPTION	Caption	HOME SMART	Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
P.MODE	Red/ P. Mode	A	Red

Original		Replacement	
S.MODE	Green/ S. Mode	B	Green
STILL	Yellow/ Still	C	Yellow
P.SIZE	Blue/ P. Size	D	Blue
MTS	MTS	AD SUBT	Subt
SRS	SRS	SOUND DUAL	Dual
PIP	PIP	ECO 3D	3D
AUTO PROG.	Auto Prog.	SEARCH TV/R	TV/ R
ADD/DEL	Add/ Del	REPEAT TEXT	Text
POSITION	Position	PICTURE FORMAT	Format
CH	CH Up	>>	>>
CH	CH Down	<<	<<

Original	Replacement