Original	Replacement	Original	Replacement
Operate	Power	<<	<< / Tune-
Rec Mode	Text / Goto	Play	Play / Slow
VCR	Shift + 4	>>	>> / Tune+
DVD	Shift + 2	VCR Rec/OTR	Rec / Rec Mode
1	1	Stop	Stop / Hold
2	2	Audio	Audio / Lang I/II
3	3	Search	Red / Netflix / Search
Prog+	CH+ / Page+	I > Slow	Shift + Play /
4	4	Pause	Pause / Step / Freeze
5	5		
6	6		
Prog-	CH- / Page-		
7	7		
8	8		
9	9		
Clear/C. Reset	Exit / Cancel / Clear		
0	0		

Original	Replacement	Original	Replacement
Operate	Power	Right	Right
Dubbing	Info / Angle	Down	Down
Setup	Setup / OPT /	Enter	OK
Open-Close/Eject	Eject / Surround	1	1
T-Set	TV/Radio /	2	2
Timer Prog./Showview	Sleep / Timer	3	3
Rec Mode	Text / Goto	4	4
Rapid Play	Smart / List	5	5
Zoom	Zoom / Size	6	6
VCR	Shift + 4	7	7
DVD	Shift + 2	8	8
CM Skip	Red / Netflix / Search	9	9
Top Menu	D.Menu / Top	Skip >>I	>>I / Preset+
Up	Up	Clear/C.Reset	Exit / Cancel / Clear
Menu/List	Menu / Home	0	0
Return/Key	Back / Return	Display	Display / Media
Left	Left	I << Skip	I << / Preset-

Original	Replacement	Original	Replacement
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Stop	Stop / Hold		
DVD/Rec OTR	Rec / Rec Mode		
Repeat	Green / APP / Repeat		
Audio	Audio / Lang I/II		
Pause	Pause / Step / Freeze		