Mandis shop

Sharp RRMCGA001SJSA

Original		Replacement	
ON/STAND-BY	On/Standby		Power
CD	CD	C	Yellow
TUNER(BAND)	Tuner/Band	B	Green
TAPE	Tape	A	Red
TUNING	<</Tuning	<<	<<
TUNING	>>/Tuning Up	>>	>>
PRESET	I<</Preset	I<<	I<<
PRESET	>>I/Preset Up	>>I	>>I
	Play	PLAY MODE	Play
	Stop		Stop
	Pause		Pause
MEMORY	Memory	HOME SMART	Smart
CLEAR	Clear	CLEAR EXIT	Exit
RANDOM/REPEAT	Random/Repeat	REPEAT TEXT	Text
CLOCK	Clock	E-MANUAL D.MENU	D. Menu
TIMER	Timer	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep

Original		Replacement	
TREBLE	Treble-		Left
TREBLE	Treble+		Right
BASS	Bass-		Down
BASS	Bass+		Up
VOLUME	Vol-	VOL	Vol -
VOLUME	Vol+	VOL	Vol +

https://all-remotes.online/en/Sharp/1063229-2558-replacement-remote-control-for-Sharp-RRMCGA001SJSA.html