Mandis shop

Sony RMT-TX102D

Original	Replacement	Original	Replacement
Input	AV / Input / RDS	Green	Green / APP / Repeat
Power	Power	Yellow	Yellow / YouTube / Repeat
Digital/Analog	Display / Media	Blue	Blue / Prime Video / Random
Sync Menu	D.Menu / Top	Netflix	Shift + Red / Netflix /
1	1	[i+]/[?]	Info / Angle
2	2	Guide	Guide / EPG / -/--
3	3	Sleep	Sleep / Timer
4	4	Up	Up
5	5	Left	Left
6	6	OK	OK
7	7	Right	Right
8	8	Return	Back / Return
9	9	Down	Down
Exit	Exit / Cancel / Clear	Options	Setup / OPT /
0	0	Home	Menu / Home
[≡]/Text	Text / Goto	Vol +	Vol +
Red	Red / Netflix / Search	Recall	Fav / Marker / PC

Original		Replacement		Original		Replacement	
PROG +	PR+	+ CH PAGE	CH+ / Page+				
—	Vol -	VOL —	Vol -				
	Mute	DIMMER MUTE	Mute / Dimmer				
—	PR-	CH PAGE —	CH- / Page-				
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II				
	[...]	EQ SUBTITLE	Subtitle / EQ				
TITLE LIST	Title List	LIST SMART	Smart / List				
◀◀	<<	TUNE- ◀◀	<< / Tune-				
▶	Play	SLOW ▶	Play / Slow				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				
⏮	I <<	PRESET- ⏮	I << / Preset-				
⏸	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze				
⏭	>>I	PRESET+ ⏭	>>I / Preset+				
REC	Rec	REC MODE ●	Rec / Rec Mode				
■	Stop	HOLD ■	Stop / Hold				
	[+]	FORMAT PICTURE	Picture / Format				