Mandis shop

Sony RMSD70S

Original		Replacement	
I / ⏻	Power	⏻	Power
SLEEP	Sleep	PROG SLEEP	Sleep
DISC SKIP	Disc Skip	HOME SMART	Smart
CD	Play CD	PLAY MODE ▶	Play
⏸	Pause CD	⏸	Pause
■	Stop CD	■	Stop
TUNER/BAN	Play	SEARCH TV/R	TV/R
⏮	I<</- Tuner/Band	⏮	I<<
⏭	>>I/+	⏭	>>I
DECK A	Play Deck A	A	Red
◀◀	<< Deck A	◀◀	<<
▶▶	>> Deck A	▶▶	>>
DECK B	Play Deck B	B	Green
CHECK	Check	SETTINGS OPT	Options
CLEAR	Clear	CLEAR EXIT	Exit
FUNCTION	Function	TOP MENU MENU	Menu
LOOP	Loop	TIMER AV	AV

Original		Replacement	
FLASH	Flash	PICTURE FORMAT	Format
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ON/OFF	On/Off	OK	Ok
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -

https://all-remotes.online/en/Sony/1060741-83073-replacement-remote-control-for-Sony-RMSD70S.html