Mandis shop

RM-177R

Original	Replacement
Audio Muting	Mute
Band Tuner	TV/R
1 Tuner	1
2 Tuner	2
3 Tuner	3
4 Tuner	4
5 Tuner	5
< Tape	Left
>Tape	Right
< Rec Tape	Shift + Left
> Rec Tape	Shift + Right
<< Tape	<<
>> Tape	>>
Stop Rec Tape	Up
Stop Tape	Ok
Pause Tape	Down
Play CD	Play

Original	Replacement
Stop CD	Stop
I << CD	I <<
>>I CD	>>I
CD	Yellow
Phono	Blue
Vol +	Vol +
Vol -	Vol -

https://al-redesonline.com/Sony-1687-855-replacement-remote-control-for-Sony-RM-177R.htm