Original		Replacement	
	Power MD		Power
	Direct Tuning	REPEAT TEXT	Text
DIMMER	Dimmer	FAV PRE-CH	Pre Ch
TV	TV	SEARCH TV/R	TV/R
CD	CD	C	Yellow
DVD	DVD	D	Blue
TUNER/ BAND	Tuner/Band	B	Green
TAPE	Tape	A	Red
VCR	VCR	HOME SMART	Smart
MD	MD	APP MEDIA	Media
VOL +	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
MUTING	Muting	MUTE	Mute
	Stop MD	■	Stop
	Play MD	PLAY MODE ▶	Play
	<<|<< MD	«	<<
	>>|>> MD	»	>>

Original		Replacement	
	Up	▲	Up
	Down	▼	Down
	Right	▶	Right
	Left	◀	Left
ENTER	Enter	OK	Ok
MENU	Menu	E-MANUAL D.MENU	D. Menu
DISPLAY	Display	DISPLAY INFO	Info
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu
1	1 MD	1	1
2	2 MD	2	2
3	3 MD	3	3
4	4 MD	4	4
5	5 MD	5	5
6	6 MD	6	6
7	7 MD	7	7
8	8 MD	8	8
9	9 MD	9	9

Original		Replacement	
0	0 MD	0	0
≥10/-/--	>10/-/-- MD	-/-- GUIDE	Guide
TV/AV	Tv/AV	TIMER AV	AV
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH −	Ch -
⏻	Power TV	SHIFT + ⏻	Shift + Power
VOL ^	Tv Vol Up	SHIFT + + VOL	Shift + Vol +
TV v	Tv Vol Down	SHIFT + VOL −	Shift + Vol -
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3

Original		Replacement	
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
0	0 Tv	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/-- Tv	SHIFT + -/-- GUIDE	Shift + Guide

Original	Replacement	Original	Replacement
Power DVD	Power	Right	Right
TV	TV/R	Left	Left
VCR	Smart	Enter	Ok
Tuner / Band	Green	Stereo	Dual
Tape	Red	Surround	Options
MD	Media	SFC	Subt
CD	Yellow	Test	Back
DVD	Blue	Delay	Format
Play DVD	Play	Level	3D
I <<< / << DVD	<<	+	Ch +
Stop DVD	Stop	-	Ch -
>>> / >>I DVD	>>	1 DVD	1
Top Menu/ Disc/ Deck	Menu	2 DVD	2
Display	Info	3 DVD	3
Menu	D. Menu	4 DVD	4
Up	Up	5 DVD	5
Down	Down	6 DVD	6

Original		Replacement		Original	Replacement
7	7 DVD	7	7		
8	8 DVD	8	8		
9	9 DVD	9	9		
0	0 DVD	0	0		
≥10/-/--	>10/-/-- DVD	-/-- GUIDE	Guide		
VOL +	Vol +	+ VOL	Vol +		
VOL −	Vol -	VOL −	Vol -		
MUTING	Muting	MUTE	Mute		

Original		Replacement	
	Power CD		Power
	TV	SEARCH TV/R	TV/R
	VCR	HOME SMART	Smart
	CD	C	Yellow
	DVD	D	Blue
	Tape	A	Red
	MD	APP MEDIA	Media
	Tuner/Band	B	Green
	Stop CD		Stop
	I<<</<< CD	<<	<<
	>>/>>I CD	>>	>>
	Play CD	PLAY MODE	Play
	Menu	E-MANUAL D.MENU	D. Menu
	Display	DISPLAY INFO	Info
	Top Menu/Disc/Deck	TOP MENU MENU	Menu
	Up		Up
	Down		Down

Original		Replacement	
	Right		Right
	Left		Left
	Enter	OK	Ok
	Stereo	SOUND DUAL	Dual
	Surround	SETTINGS OPT	Options
	SFC	AD SUBT	Subt
	Test	RETURN BACK	Back
	Delay	PICTURE FORMAT	Format
	Level	ECO 3D	3D
	+	+ CH	Ch +
	-	CH −	Ch -
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Muting	MUTE	Mute
	Power Tape	SHIFT +	Shift + Power
	Stop Tape	SHIFT +	Shift + Stop
	Play Tape	SHIFT + PLAY MODE	Shift + Play

Original	Replacement	Original	Replacement
I <<| << Tape	SHIFT + << Shift + <<		
>>| >>I Tape	SHIFT + >> Shift + >>		
Top Menu/ Disc/ Deck	SHIFT + TOP MENU MENU Shift + Menu		
1 CD- Tape	1 1		
2 CD- Tape	2 2		
3 CD- Tape	3 3		
4 CD- Tape	4 4		
5 CD- Tape	5 5		
6 CD- Tape	6 6		
7 CD- Tape	7 7		
8 CD- Tape	8 8		
9 CD- Tape	9 9		
0 CD- Tape	0 0		
>10/ - / - - CD- Tape	-/-- GUIDE Guide		
Direct Tuning/ Disc Ente	REPEAT TEXT Text		

Original	Replacement
Power VCR	Power
Dimmer	Pre Ch
VCR	Smart
Tape	Red
TV	TV/R
CD	Yellow
DVD	Blue
Tuner/Band	Green
MD	Media
Stop	Stop
I <<< / <<	<<
>>/ >>I	>>
Play	Play
1 VCR	1
2 VCR	2
3 VCR	3
4 VCR	4

Original	Replacement
5 VCR	5
6 VCR	6
7 VCR	7
8 VCR	8
9 VCR	9
0 VCR	0
>10/-/-- VCR	Guide
Direct Tuning/Disc Ente	Text
Vol +	Vol +
Vol -	Vol -
Muting	Mute
Up	Up
Down	Down
Right	Right
Left	Left
Enter	Ok
Top Menu/Disc/Deck	Menu

1/2

Original	Replacement
Display	Info
Menu	D. Menu
Stereo	Dual
Surround	Options
SFC	Subt
Test	Back
Delay	Format
Level	3D
+	Ch +
-	Ch -
Power Tuner / Band	Shift + Power
1 Tuner / Band	Shift + 1
2 Tuner / Band	Shift + 2
3 Tuner / Band	Shift + 3
4 Tuner / Band	Shift + 4
5 Tuner / Band	Shift + 5
6 Tuner / Band	Shift + 6

Original	Replacement
7 Tuner / Band	Shift + 7
8 Tuner / Band	Shift + 8
9 Tuner / Band	Shift + 9
0 Tuner / Band	Shift + 0
>10/ - / - -	Shift + Guide