| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| – LEVE | Level - | CH PAGE – | CH- / Page- |
| – LEVE | Level - | VOL – | Vol - |
| EVEL + | Level + | + CH PAGE | CH+ / Page+ |
| EVEL + | Level + | + VOL | Vol + |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| ≥10 | +10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| PROGRAM | Program | PROGRAM TV/ RADIO | TV/ Radio / Program |

| Original | | Replacement | |
|---|---|---|---|
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| RECALL | Recall | RETURN BACK | Back / Return |
| TIME MODE | Time Mode | TIMER SLEEP | Sleep / Timer |
| A-B REPEAT | A-B Repeat | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| REPEAT | Repeat | APP REPEAT | Green / APP / Repeat |
| RANDOM | Random | Prime Video RANDOM | Blue / Prime Video / Random |
| AUTO CUE | Auto Cue | LIST SMART | Smart / List |
| TAPE LENGTH | Tape Length | | Up |
| SIDE A/B | Side A-B | | Left |
| TIME FADE | Time Fade | | Right |
| PEAK SEARCH | Peak Search | NETFLIX SEARCH | Red / Netflix / Search |
| PEAK SEARCH | Peak Search | | Down |
| SEA | << Search | TUNE- | << / Tune- |
| RCH | Search >> | TUNE+ | >> / Tune+ |
| OPEN/CLOSE | Open/Close | SURROUND | Eject / Surround |
| SK | I<< Skip | PRESET- | I<< / Preset- |
| KIP | Skip >>I | PRESET+ | >>I / Preset+ |

| Original | Replacement |
|---|---|
| Pause | Pause / Step / Freeze |
| Stop | Stop / Hold |
| Play | Play / Slow |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |