Original		Replacement	
	Power		Power
	HDMI Control	E-MANUAL D.MENU	D. Menu
RECORD	Record	REC MODE	Rec
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	I <<		I <<
	<<		<<
	>>		>>
	>>I		>>I
SCREEN	Screen	PICTURE FORMAT	Format
LANG	Lang	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
	Internet	APP MEDIA	Media
ZOOM	Red/ Zoom/ ↑	A	Red
REPEAT	Green/ Repeat / ↓	B	Green
ROOT	Yellow / Root	C	Yellow

Original		Replacement	
TITLE	Blue / Title	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TEXT	Text	REPEAT TEXT	Text
SWAP	Swap	FAV PRE-CH	Pre Ch
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement		Original	Replacement
OK	Ok	OK	Ok		
P/CH +	P/Ch+	CH +	Ch +		
P/CH −	P/Ch-	CH −	Ch -		
+	Vol +	VOL +	Vol +		
−	Vol -	VOL −	Vol -		
	Mute	MUTE	Mute		
MENU	Menu	TOP MENU MENU	Menu		
SOURCE	Source	TIMER AV	AV		
RETURN	Return	RETURN BACK	Back		
EPG	Epg	-/-- GUIDE	Guide		
INFO	Info	DISPLAY INFO	Info		
SLEEP	Sleep	PROG SLEEP	Sleep		
3D	3D	ECO 3D	3D		
SEARCH MODE	Search Mode	SEARCH TV/R	TV/R		
	Music/Movie/Phot	HOME SMART	Smart		
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info		
PRESETS	Presets	SETTINGS OPT	Options		