Mandis shop

Yamaha WY92710

Original	Replacement	Original	Replacement
Power	Power	Play	Play
Sleep	Sleep	Pause	Pause
CD	1	>>I	>>I
iPod	2	I <<	I <<
AUX	3	Stop	Stop
Tuner	4	Option	Options
USB	6	Back	Back
Folder Down	Ch -	X	Media
Folder Up	Ch +	Display	Info
←	<<	Vol +	Vol +
→	>>	Vol -	Vol -
Up	Up	Mute	Mute
Down	Down	<< Tuning	Red
Right	Right	Tuning >>	Green
Left	Left	< Preset	Yellow
Enter	Ok	Memory	TV/R
Menu	Menu	Preset >	Blue

https://al-remotes.com/en/Yamaha/1503257-replacement-remote-control-for-Yamaha-WY92710-WY92710.htm