Mandis shop

Yamaha RAX12

Original	Replacement	Original	Replacement
Standby/On	Power	Preset + Tuner	Ch +
Vol +	Vol +	Preset - Tuner	Ch -
Vol -	Vol -	CD	2
Sleep	Sleep	Phono	1
AUX	6	Play CD Phono	Play
Tape 1	4	Pause/Stop CD	Stop
Tape 2	5	Disc CD Phono	Media
Dir A Tape	Guide	>> CD Phono	>>
Dir B Tape	Pre Ch	<< CD Phono	<<
Rec/Pause Tape	Up	>>I CD Phono	>>I
Play Tape	Ok	I << CD Phono	I <<
Stop Tape	Down		
>> Tape	Right		
<< Tape	Left		
A/B Tape	0		
Tuner	3		
A/BC/D/E Tuner	Back		

https://al-remotes.online/en/Yamaha/1034262/replacement-remote-control-for-Yamaha-RAX12-WB72180.htm