










































Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 Nicam/A2	 Shift + Audio / Lang I/II
 Aspect	 Shift + Picture / Format
 P.Mode	 Picture / Format
 S.Mode	 Sound / Title
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 -/--	 Shift + Guide / EPG / -/--
 0	 0

Original	Replacement
 Recall	 Back / Return
 Display	 Display / Media
 Freeze	 Pause / Step / Freeze
 Rec/Auto	 Rec / Rec Mode
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Sleep	 Sleep / Timer
 Up	 Up
 Source	 AV / Input / RDS
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 Menu	 Menu / Home
 Exit	 Exit / Cancel / Clear





Original	Replacement	Original	Replacement
CH+ <small>CH</small>	CH+ / Page+ <small>CH PAGE</small>	DTV	Smart / List <small>LIST SMART</small>
Subtitle <small>SUBTITLE</small>	Subtitle / EQ <small>SUBTITLE EQ</small>	EPG	Guide / EPG / -/- <small>GUIDE EPG</small>
Vol+ <small>VOL</small>	Vol+ <small>VOL</small>	Tv/Radio <small>TV/RADIO</small>	TV/Radio / <small>TV/RADIO</small>
CH- <small>CH</small>	CH- / Page- <small>CH PAGE</small>		
T.Shift <small>T.SHIFT</small>	Setup / OPT / <small>OPT-TOOLS SETUP</small>		
Vol- <small>VOL</small>	Vol- <small>VOL</small>		
Play/Pause/Hold <small>HOLD</small>	Play / Slow <small>SLOW</small>		
Play/Pause/Hold <small>HOLD</small>	Shift + Stop / <small>SHIFT</small> + <small>HOLD</small>		
<</Reveal <small>REVEAL</small>	<< / Tune- <small>TUNE-</small>		
>>/Size <small>SIZE</small>	Zoom / Size <small>SIZE ZOOM</small>		
>>/Size <small>SIZE</small>	>> / Tune+ <small>TUNE+</small>		
Stop/Index <small>INDEX</small>	Stop / Hold <small>HOLD</small>		
I<< <small>PRESET-</small>	I<< / Preset- <small>PRESET-</small>		
S.Page/>>I <small>S.PAGE</small>	>>I / Preset+ <small>PRESET+</small>		
Text <small>TEXT</small>	Text / Goto <small>GOTO TEXT</small>		
FAV <small>FAV</small>	Fav / Marker / PC <small>PC FAV MARKER</small>		
Audio <small>AUDIO</small>	Audio / Lang I/II <small>LANG I/II AUDIO</small>		

