














































































































| Original | | Replacement | | Original | | Replacement | |
|---|------------|---|---------|---|----------------------|---|--------------|
|  | Standby/On |  | Power |  | I<< |  | I<< |
|  | 1 |  | 1 |  | >>I |  | >>I |
|  | 2 |  | 2 |  | Play |  | Play |
|  | 3 |  | 3 |  | Stop |  | Stop |
|  | 4 |  | 4 |  | << |  | << |
|  | 5 |  | 5 |  | >> |  | >> |
|  | 6 |  | 6 |  | Mute |  | Mute |
|  | 7 |  | 7 |  | Prog+ |  | Ch + |
|  | 8 |  | 8 |  | Prog- |  | Ch - |
|  | 9 |  | 9 |  | Vol+ |  | Vol + |
|  | 0 |  | 0 |  | Vol- |  | Vol - |
|  | Tv/DVD |  | TV/R |  | Menu |  | Menu |
|  | Open/Close |  | Eject |  | Return |  | Back |
|  | DTV/Analog |  | Smart |  | Exit |  | Exit |
|  | Input Sel |  | AV |  | Title List/Disc Menu |  | Media |
|  | Copy |  | Options |  | Play List/Title Menu |  | Shift + Menu |
|  | Pause |  | Pause |  | Red |  | Red |





| Original | Replacement |
|---|---|
|  |  |
| Green | Green |
|  |  |
| Yellow | Yellow |
|  |  |
| Blue | Blue |
|  |  |
| Guide | Guide |
|  |  |
| Info | Info |
|  |  |
| Subtitle | Subt |
|  |  |
| Text | Text |
|  |  |
| Tv/Radio | Sleep |
|  |  |
| FAV List | Pre Ch |
|  |  |
| Marker | Shift + Options |
|  |  |
| Rec | Rec |
|  |  |
| Audio | Dual |
|  |  |
| Rec Mode | Shift + Rec |
|  |  |
| Rec | Format |
|  |  |
| Repeat | Shift + Text |
|  |  |
| OK | Ok |
|  |  |
| Up | Up |

| Original | Replacement |
|---|---|
|  |  |
| Down | Down |
|  |  |
| Right | Right |
|  |  |
| Left | Left |
|  |  |
| USB | Shift + Media |
|  |  |
| Timer | Shift + AV |
|  |  |
| HDD | Shift + Smart |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |







































































| | Original | Replacement | Original | Replacement |
|--|---------------|-------------|----------|-------------|
| | Input Sel | | | |
| | 1 | | | |
| | 2 | | | |
| | 3 | | | |
| | 4 | | | |
| | 5 | | | |
| | 6 | | | |
| | 7 | | | |
| | 8 | | | |
| | 9 | | | |
| | 0 | | | |
| | Prog+ | | | |
| | Prog- | | | |
| | Standby/On TV | | | |
| | Mute Tv | | | |
| | Tv Vol+ | | | |
| | Tv Vol- | | | |
































| Original | Replacement | Original | Replacement |
|--|---|--|--|
|  Standby/On |  Power |  I<< |  I<< |
|  1 |  1 |  >>I |  >>I |
|  2 |  2 |  Play |  Play |
|  3 |  3 |  Stop |  Stop |
|  4 |  4 |  << |  << |
|  5 |  5 |  >> |  >> |
|  6 |  6 |  Prog+ |  Ch + |
|  7 |  7 |  Prog- |  Ch - |
|  8 |  8 |  Menu |  Menu |
|  9 |  9 |  Return |  Back |
|  0 |  0 |  Exit |  Exit |
|  Tv/DVD |  TV/R |  Title List/Disc Menu |  Media |
|  Open/Close |  Eject |  Play List/Title Menu |  Shift + Menu |
|  DTV/Analog |  Smart |  Red |  Red |
|  Input Sel |  AV |  Green |  Green |
|  Copy |  Options |  Yellow |  Yellow |
|  Pause |  Pause |  Blue |  Blue |





| Original | Replacement | Original | Replacement |
|---|-------------|--|-----------------|
|  | Guide |  | Guide |
|  | Info |  | Info |
|  | Subtitle |  | Subt |
|  | Text |  | Text |
|  | Tv/Radio |  | D. Menu |
|  | FAV List |  | Pre Ch |
|  | Marker |  | Shift + Options |
|  | Rec |  | Rec |
|  | Audio |  | Dual |
|  | Rec Mode |  | Shift + Rec |
|  | Rec |  | Format |
|  | Repeat |  | Shift + Text |
|  | OK |  | Ok |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |

| Original | Replacement | Original | Replacement |
|---|-------------|---|---------------|
|  | USB |  | Shift + Media |
|  | Timer |  | Shift + AV |
|  | HDD |  | Shift + Smart |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

