






































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	DTV/ATV		Smart
	Return		Back
	P.Mode		Shift + Format
	S.Mode		Shift + Dual
	Sleep		Sleep

Original	Replacement	Original	Replacement
	Menu		Menu
	Exit		Exit
	Source		AV
	Display		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Lang/Audio		Dual
	Reclist		List
	Rec		Rec
	FAV/List		Pre Ch
	Freeze		Media
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +





Original		Replacement		Original		Replacement	
	CH-		Ch -		Green		Green
	EPG		Guide		Yellow		Yellow
	Aspect		3D		Blue		Blue
	<<		<<				
	>>		>>				
	Pause/Timeshift		Pause				
	I<</Cancel		I<<				
	>>I/Sub.Pg		>>I				
	Stop/Index		Stop				
	Play		Play				
	Tv/Radio		TV/R				
	Subtitle		Subt				
	Reveal		Options				
	Size		Format				
	Hold		Eject				
	Text		Text				
	Red		Red				

