







































































	Original	Replacement		Original	Replacement		
	Step		Power		Angle		Red
	Search		TV/R		Audio		Dual
	Mute		Mute		Menu PBC		Menu
	Source		AV		Title		List
	1		1		Up		Up
	2		2		Setup		Options
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		Enter		Ok
	7		7		Vol+		Vol +
	8		8		Vol-		Vol -
	9		9		Mode		Exit
	0		0		Stop		Stop
	10+		Guide		Play		Play
	Display		Info		Pause		Pause
	Subtitle		Subt		>>		>>





	Original	Replacement	Original	Replacement
	I<<		I<<	
	>>		>>	
	<<		<<	
	Repeat		Text	
	Slow		3D	
	Program		Sleep	
	Zoom		Eject	

