



























| Original | | Replacement | | Original | | Replacement | |
|---|--------|---|-------|---|----------|---|----------------|
|  | POWER |  | Power |  | INFO |  | Info |
|  | MUTE |  | Mute |  | TV/RADIO |  | TV/R |
|  | 1 |  | 1 |  | CH+ |  | Ch + |
|  | 2 |  | 2 |  | CH- |  | Ch - |
|  | 3 |  | 3 |  | LCD MENU |  | Menu |
|  | 4 |  | 4 |  | DVB MENU |  | D. Menu |
|  | 5 |  | 5 |  | Up |  | Up |
|  | 6 |  | 6 |  | Down |  | Down |
|  | 7 |  | 7 |  | Right |  | Right |
|  | 8 |  | 8 |  | Left |  | Left |
|  | 9 |  | 9 |  | Enter |  | Ok |
|  | 0 |  | 0 |  | INPUT |  | AV |
|  | -/-- |  | Guide |  | PMODE |  | Shift + Format |
|  | Recall |  | Back |  | SMODE |  | Dual |
|  | VOL+ |  | Vol + |  | SLEEP |  | Sleep |
|  | VOL- |  | Vol - |  | LIST |  | List |
|  | NICAM |  | Smart |  | FAV |  | Pre Ch |





| Original | | Replacement | | Original | | Replacement | |
|---|--------------|---|---------------|----------|--|-------------|--|
|  | PAGE- |  | << | | | | |
|  | PAGE+ |  | >> | | | | |
|  | TEXT |  | Text | | | | |
|  | HOLD |  | Options | | | | |
|  | EXIT |  | Exit | | | | |
|  | EPG |  | Shift + Guide | | | | |
|  | INDEX |  | 3D | | | | |
|  | SUBTITLE |  | Subt | | | | |
|  | SIZE |  | Format | | | | |
|  | REVEAL |  | Media | | | | |
|  | RED |  | Red | | | | |
|  | GREEN/AUDIO |  | Green | | | | |
|  | YELLOW/PAUSE |  | Yellow | | | | |
|  | BLUE |  | Blue | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

