























































































































Original	Replacement	Original	Replacement
 Power	 Power	 4	 4
 Mute	 Mute / Dimmer	 5	 5
 Play	 Play / Slow	 6	 6
 Pause/[≡]	 Pause / Step / Freeze	 7	 7
 Stop/[≡+]	 Stop / Hold	 8	 8
 Rec/[≡◆]	 Rec / Rec Mode	 9	 9
 <</[≡o]	 << / Tune-	 *	 Setup / OPT /
  <</[≡i]	  << / Preset-	 0	 0
 >> /[≡?]	 >>  / Preset+		 Up
 >> /[≡x]	 >> / Tune+	 [→]	 AV / Input / RDS
 Info	 Info / Angle		 Left
 OI/II/Audio	 Audio / Lang I/II	 OK	 OK
 [≡]	 Text / Goto		 Right
 ←/<x]	 Fav / Marker / PC		 Down
 1	 1	 Netflix	 Shift + Red / Netflix /
 2	 2	 You Tube	 Shift + Yellow / YouTube /
 3	 3	 +	 Vol+







Original		Replacement		Original		Replacement	
	Power		Power		4		4
	Mute		Mute / Dimmer		5		5
	Play		Play / Slow		6		6
	Pause [ /≡]		Pause / Step / Freeze		7		7
	Stop/[≡+]		Stop / Hold		8		8
	Rec/[≡◆]		Rec / Rec Mode		9		9
	<</[≡o]		<< / Tune-		*		Setup / OPT /
	<</[≡i]		<< / Preset-		0		0
	>> /[≡?]		>>  / Preset+		[→]		AV / Input / RDS
	>> /[≡x]		>> / Tune+		Up		Up
	Info		Info / Angle		Left		Left
	O)/II/Audio		Audio / Lang I/II		OK		OK
	[≡]		Text / Goto		Right		Right
	←/<x]		Fav / Marker / PC		Down		Down
	1		1		Netflix		Shift + Red / Netflix /
	2		2		YouTube		Shift + Yellow / YouTube /
	3		3		Vol+		Vol+



