








Original	Replacement
TV	TV/R
Video	Smart
PC	Media
Text	Text
P+	Ch +
Up	Up
P-	Ch -
Down	Down
Right	Right
Vol+	Vol +
Left	Left
Vol-	Vol -
Menu	Menu
Menu	Ok
Mute	Mute
Red / M	Red
Green	Green

Original	Replacement
Yellow	Yellow
Blue	Blue
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/-	Guide
L / ?	List
Freeze	Pause
M/S	Options
PIP	3D





Original	Replacement	Original	Replacement
 Auto	 Back		
 F[+]	 Format		
 i	 Info		
 F1	 Shift + 1		
 Clock	 AV		
 F2	 Shift + 2		
 F3	 Shift + 3		
 F4	 Shift + 4		
 Power	 Power		

