



| Original | Replacement |
|--|---|
|  Power |  Power |
|  Mute |  Mute / Dimmer |
|  V-Format |  Picture / Format |
|  Sleep |  Sleep / Timer |
|  FAV |  Fav / Marker / PC |
|  TV / Radio |  TV/Radio / |
|  List |  Smart / List |
|  SAT |  Shift + 0 |
|  Zoom |  Zoom / Size |
|  Subtitle |  Subtitle / EQ |
|  Vol + |  Vol+ |
|  Info |  Info / Angle |
|  CH+ |  CH+ / Page+ |
|  Vol - |  Vol- |
|  Recall |  Back / Return |
|  CH- |  CH- / Page- |
|  Menu |  Menu / Home |

| Original | Replacement |
|---|---|
|  Text |  Text / Goto |
|  Guide |  Guide / EPG / -/- |
|  Exit |  Exit / Cancel / Clear |
|  Up |  Up |
|  Page Down |  Shift + CH- / |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Page Up |  Shift + CH+ / |
|  Down |  Down |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |



