


















| Original  | Replacement  | Original  | Replacement  |
|---|--|---|--|
|  Power     |  Power            |  Still           |  Pause        |
|  Mute      |  Mute             |  S.Mode          |  Shift + Dual |
|  1         |  1                |  Sleep           |  Sleep        |
|  2         |  2                |  Volume+         |  Vol +        |
|  3         |  3                |  Volume-         |  Vol -        |
|  4         |  4                |  Channel+        |  Ch +         |
|  5         |  5                |  Channel-        |  Ch -         |
|  6         |  6                |  PIP On/Off      |  Smart        |
|  7         |  7                |  Source          |  Shift + AV   |
|  8         |  8                |  Size            |  Eject        |
|  9        |  9               |  Swap           |  Back        |
|  0       |  0              |  Up / P-CH +   |  Up         |
|  -/--    |  Guide          |  Down / P-CH - |  Down       |
|  Preview |  Pre Ch         |  Right         |  Right      |
|  Sound   |  Dual           |  Left          |  Left       |
|  Picture |  Shift + Format |  Menu          |  Menu       |
|  Aspect  |  Format         |  Menu          |  Ok         |

| Original  | Replacement  | Original  | Replacement  |
|---|--|---|--|
|  Power     |  Power            |  Still           |  Pause        |
|  Mute      |  Mute             |  S.Mode          |  Shift + Dual |
|  1         |  1                |  Sleep           |  Sleep        |
|  2         |  2                |  Volume+         |  Vol +        |
|  3         |  3                |  Volume-         |  Vol -        |
|  4         |  4                |  Channel+        |  Ch +         |
|  5         |  5                |  Channel-        |  Ch -         |
|  6         |  6                |  PIP On/Off      |  Smart        |
|  7         |  7                |  Source          |  Shift + AV   |
|  8         |  8                |  Size            |  Eject        |
|  9        |  9               |  Swap           |  Back        |
|  0       |  0              |  Up / P-CH +   |  Up         |
|  -/--    |  Guide          |  Down / P-CH - |  Down       |
|  Preview |  Pre Ch         |  Right         |  Right      |
|  Sound   |  Dual           |  Left          |  Left       |
|  Picture |  Shift + Format |  Menu          |  Menu       |
|  Aspect  |  Format         |  Menu          |  Ok         |





| Original  |             | Replacement   |               |
|---|-------------|---|---------------|
|    | Exit        |    | Exit          |
|    | TV / AV     |    | AV            |
|    | Info        |    | Info          |
|    | Wiper       |    | Media         |
|    | PC Auto     |    | Options       |
|    | TTX On/Off  |    | Text          |
|    | TTX / Mix   |    | Shift + Text  |
|    | Index       |    | Shift + Info  |
|    | List / FLOF |    | Shift + Smart |
|   | Store       |   | TV/R          |
|  | Hold        |  | Stop          |
|  | Reveal      |  | Shift + Subt  |
|  | Subpage     |  | Subt          |
|  | Size        |  | Shift + Eject |
|  | Red         |  | Red           |
|  | Green       |  | Green         |
|  | Yellow      |  | Yellow        |

| Original  |      | Replacement   |      |
|---|------|---|------|
|  | Blue |  | Blue |

