

































































Original		Replacement		Original		Replacement	
	1		1		>>		>>
	2		2		PLAY/PAUSE		Play
	3		3		I<<		I<<
	4		4		>>I		>>I
	5		5		EJECT		Eject
	6		6		MUTE		Mute
	7		7		VOLUME+		Vol +
	8		8		VOLUME-		Vol -
	9		9		INPUT CD		Yellow
	0		0		INPUT TUNER		Green
	TIME		AV		INPUT AUX		Red
	REPEAT		Text		INPUT VIDEO		Blue
	REPEAL A-B		TV/R		INPUT TAPE 1		Guide
	DISPLAY		Info		INPUT TAPE 2		Pre Ch
	STOP		Stop				
	PAUSE		Pause				
	<<		<<				

