



Original	Replacement	Original	Replacement
 Timer On/Sleep	 Sleep	 Intro/PTY	 Ok
 FM Mode/Play	 TV/R	 I<<<</Tuning	 I<<
 Clock/Timer	 AV	 >>>>/Tuning	 >>I
 Function	 Menu	 MP3 Folder/Preset Down	 Ch -
 1	 1	 MP3 Folder/Preset Up	 Ch +
 2	 2	 Stop/Band	 Stop
 3	 3	 Play	 Play
 4	 4	 Pause	 Pause
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 Muting	 Mute
 8	 8	 Standby/On	 Power
 9	 9		
 0	 0		
 Digit	 Pre Ch		
 Memory/Time	 Smart		
 MP3/RDS	 Media		

