


































































Original	Replacement	Original	Replacement
 Standby	 Power	 Canc	 Exit / Cancel / Clear
 Equalizzatore	 Shift + Sound / Title	 0/10	 0
 Surround	 Shift + Eject / Surround	 10+	 Guide / EPG / -/-
 Eject	 Eject / Surround	 Titolo	 Sound / Title
 Audio	 Audio / Lang I/II	 Up	 Up
 1	 1	 Menu	 Menu / Home
 2	 2	 Left	 Left
 3	 3	 OK	 OK
 Angle	 Info / Angle	 Right	 Right
 4	 4	 Programm	 TV/Radio /
 5	 5	 Down	 Down
 6	 6	 Display	 Display / Media
 Sottotitoli	 Subtitle / EQ	 PAL/NTSC	 D.Menu / Top
 7	 7	 Setup	 Setup / OPT /
 8	 8	 Digest	 Shift + D.Menu / Top Menu
 9	 9	 Vol+	 Vol+
 Ricerca	 Red / Netflix / Search	 Mute	 Mute / Dimmer





Original		Replacement		Original		Replacement	
	Mark		Fav / Marker / PC				
	Zoom		Zoom / Size				
	Vol-		Vol-				
	A-B		Yellow / YouTube / Repeat				
	Ripeti		Back / Return				
	Slow		Shift + Play /				
	<</F.RWD		<< / Tune-				
	F.FWD/>>		>> / Tune+				
	I<< / Skip-		I<< / Preset-				
	>>I / Skip+		>>I / Preset+				
	Stop		Stop / Hold				
	Pause/Step		Pause / Step / Freeze				
	Play		Play / Slow				

