








































































Original		Replacement		Original		Replacement	
	Standby		Power		Exit		Exit
	Mute		Mute		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		CH/PG+		Ch +
	6		6		CH/PG-		Ch -
	7		7		Vol+		Vol +
	8		8		Vol-		Vol -
	9		9		TV/STB		Media
	0		0		EPG		Guide
	SAT List		Smart		FAV		Pre Ch
	TV/R		TV/R		Red/Audio		Red
	Menu		Menu		Green/Subt		Green
	Info		Info		Yellow/Text		Yellow
	Back		Back		Blue/Sleep		Blue





Original	Replacement	Original	Replacement
 PAUSE	 Pause		
 ZOOM	 Eject		
 PAL/NTSC	 Format		
 OPTION	 Options		

