

























































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Shift + Guide
 Back	 Back
 P.Mode	 Shift + Format
 S.Mode	 Dual
 Sleep	 Sleep

Original	Replacement
 Vol+	 Vol +
 Vol-	 Vol -
 Aspect	 Format
 CH+	 Ch +
 CH-	 Ch -
 MTS	 Media
 Set	 Pre Ch
 Home	 Smart
 Mouse	 TV/R
 Menu	 Menu
 Source	 AV
 Up	 Up
 Left	 Left
 Enter	 Ok
 Right	 Right
 Down	 Down
 Exit	 Exit





Original		Replacement	
	Display		Info
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	<< / Text		<<
	<< / Text		Text
	Play/Pause /		Play
	Play/Pause /		Pause
	>> / Reveal		>>
	I<< / Cancel		I<<
	>> / Freeze		>>
	Stop / Index		Stop
	EPG		Guide
	Rec		Rec
	Sub-T		Subt
	Size		Eject

Original		Replacement	
	Hold		Shift + Stop
	Mix		Shift + Text

