



| Original | Replacement          | Original | Replacement                 |
|----------|----------------------|----------|-----------------------------|
| Power    | Power                | Menu     | Menu / Home                 |
| Tv       | TV/Radio /           | Return   | Shift + Back / Return       |
| 1        | 1                    | Info     | Info / Angle                |
| 2        | 2                    | Internet | Smart / List                |
| 3        | 3                    | Exit     | Exit / Cancel / Clear       |
| 4        | 4                    | Up       | Up                          |
| 5        | 5                    | Down     | Down                        |
| 6        | 6                    | Right    | Right                       |
| 7        | 7                    | Left     | Left                        |
| 8        | 8                    | Red      | Red / Netflix / Search      |
| 9        | 9                    | Enter    | Shift + OK                  |
| 0        | 0                    | Green    | Green / APP / Repeat        |
| Enter    | OK                   | Yellow   | Yellow / YouTube / Repeat   |
| PRE-CH   | Back / Return        | Blue     | Blue / Prime Video / Random |
| CH LIST  | Shift + Smart / List | Vol+     | Vol+                        |
| FAV CH   | Fav / Marker / PC    | Vol-     | Vol-                        |
| Tools    | Setup / OPT /        | Mute     | Mute / Dimmer               |



Tools

