



Original	Replacement
Power	Power
Input	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/--	GUIDE
Pre CH	PRE-CH
<<	<<
Stop	Stop
Play	Play

Original	Replacement
>>	>>
V.Menu	D. Menu
Mute	Mute
P+	Ch +
P+	Up
P-	Ch -
P-	Down
Vol+	Right
Vol+	Vol +
Vol-	Left
Vol-	Vol -
Menu	Menu
Display	Info
P.STD	3D
Rec	Rec
Eject	Eject
Pause / P/S	Pause





Original	Replacement
Crystal PB	TV/R
TRK up	>>I
TRK Down	I<<<
Index	List
Memory	Ok
Sleep	Sleep
Lang.Sel	Dual
Clear	Exit
ShowView	Smart
Mix	Shift + Text
Text Size	Format
Subpage	Subt
TV/Text	Text

Original	Replacement

