









| Original                                                                                         | Replacement                                                                                                |
|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
|  Mute           |  Mute / Dimmer            |
|  Power          |  Power                    |
|  1              |  1                        |
|  2              |  2                        |
|  3              |  3                        |
|  4              |  4                        |
|  5              |  5                        |
|  6              |  6                        |
|  7              |  7                        |
|  8              |  8                        |
|  9             |  9                       |
|  ✓            |  Guide / EPG / -/--     |
|  0            |  0                      |
|  Red / <<<    |  Red / Netflix / Search |
|  Red / <<<    |  <<< / Tune-            |
|  Green / Stop |  Green / APP / Repeat   |
|  Green / Stop |  Stop / Hold            |

| Original                                                                                            | Replacement                                                                                                     |
|-----------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
|  Yellow / Play   |  Play / Slow                 |
|  Yellow / Play   |  Yellow / YouTube / Repeat   |
|  Blue / >>>      |  >>> / Tune+                 |
|  Blue / >>>      |  Blue / Prime Video / Random |
|  Up              |  Up                          |
|  Left            |  Left                        |
|  OK              |  OK                          |
|  Right           |  Right                       |
|  Down            |  Down                        |
|  SFI             |  D.Menu / Top                |
|  Exit / Recall  |  Back / Return              |
|  Exit / Recall |  Exit / Cancel / Clear     |
|  Info          |  Info / Angle              |
|  Prog +        |  CH+ / Page+               |
|  TV / Radio    |  TV/Radio /                |
|  Vol +         |  Vol+                      |
|  Prog -        |  CH- / Page-               |







| Original                                                                            | Replacement                                                                                                            |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|
|    | Mute / Dimmer                                                                                                          |
|    | Power                                                                                                                  |
|    | 1                                                                                                                      |
|    | 2                                                                                                                      |
|    | 3                                                                                                                      |
|    | 4                                                                                                                      |
|    | 5                                                                                                                      |
|    | 6                                                                                                                      |
|    | 7                                                                                                                      |
|    | 8                                                                                                                      |
|    | 9                                                                                                                      |
|  | Guide / EPG / -/--                                                                                                     |
|  | 0                                                                                                                      |
|  | SHIFT +  Shift + Yellow / YouTube / |
|  | << / Tune-                                                                                                             |
|  | Red / Netflix / Search                                                                                                 |
|  | Green / APP / Repeat                                                                                                   |

| Original                                                                              | Replacement                 |
|---------------------------------------------------------------------------------------|-----------------------------|
|    | Stop / Hold                 |
|    | Play / Slow                 |
|    | Yellow / YouTube / Repeat   |
|    | >> / Tune+                  |
|    | Blue / Prime Video / Random |
|    | Up                          |
|    | Left                        |
|    | OK                          |
|    | Right                       |
|    | Down                        |
|    | D.Menu / Top                |
|  | Exit / Cancel / Clear       |
|  | Back / Return               |
|  | Info / Angle                |
|  | CH+ / Page+                 |
|  | TV/Radio /                  |
|  | Vol+                        |







| Original                                                                                         | Replacement                                                                                                     |
|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
|  Mute           |  Mute / Dimmer                 |
|  Power          |  Power                         |
|  1              |  1                             |
|  2              |  2                             |
|  3              |  3                             |
|  4              |  4                             |
|  5              |  5                             |
|  6              |  6                             |
|  7              |  7                             |
|  8              |  8                             |
|  9             |  9                            |
|  ✓            |  Guide / EPG / -/--          |
|  0            |  0                           |
|  A/B          |  Shift + Yellow / YouTube / |
|  Red / <<     |  Red / Netflix / Search     |
|  Red / <<     |  << / Tune-                 |
|  Green / Stop |  Stop / Hold                |

| Original                                                                                            | Replacement                                                                                                     |
|-----------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
|  Green / Stop    |  Green / APP / Repeat        |
|  Yellow / Play   |  Play / Slow                 |
|  Yellow / Play   |  Yellow / YouTube / Repeat   |
|  Blue / >>       |  >> / Tune+                  |
|  Blue / >>       |  Blue / Prime Video / Random |
|  Up              |  Up                          |
|  Left            |  Left                        |
|  OK              |  OK                          |
|  Right           |  Right                       |
|  Down            |  Down                        |
|  SFI            |  D.Menu / Top               |
|  Exit / Recall |  Back / Return             |
|  Exit / Recall |  Exit / Cancel / Clear     |
|  Info          |  Info / Angle              |
|  Prog +        |  CH+ / Page+               |
|  TV / Radio    |  TV/Radio /                |
|  Vol +         |  Vol+                      |



