











































































































Original	Replacement	Original	Replacement
 Power	 Power	 Green	 Green
 Mute	 Mute	 Yellow	 Yellow
 [> <]	 Subt	 Blue	 Blue
 Input	 AV	 []	 TV/R
 1	 1	 [≡]	 Text
 2	 2	 MENU	 Menu
 3	 3	 Guide	 Guide
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 OK	 Ok
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 [i+] / [?]	 Info	 Prog+	 Ch +
 Recall / - / -	 Pre Ch	 Prog-	 Ch -
 Red	 Red		
























































	Original	Replacement		Original	Replacement
	Power		Power		<<
	Mute		Mute		Play
	[> <]		Subt		Vol +
	Input		AV		Vol -
	[i+]/[?]		Info		
	♪		Dual		
	*		Format		
	[+]		3D		
	[]		TV/R		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		Ok		
	Pause		Pause		
	Stop		Stop		
	>>		>>		





	Original	Replacement		Original	Replacement
	Power		Power		Format
	Mute		Mute		3D
	[> <]		Subt		TV/R
	Input		AV		Up
	1		1		Down
	2		2		Right
	3		3		Left
	4		4		Ok
	5		5		Pause
	6		6		Stop
	7		7		>>
	8		8		<<
	9		9		Play
	0		0		Rec
	[i+]/[?]		Info		Vol +
	-/--/Recall		Pre Ch		Vol -
	♪		Dual		Ch +



