










































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	02		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	i		Info
	0		0
	R		Back
	□		Media
	Sleep		Sleep
	■		Smart
	Up / P+		Up
	Up / P+		Ch +
	Audio		Dual
	Left / Vol-		Left
	Left / Vol-		Vol -
	Right / Vol+		Right
	Right / Vol+		Vol +
	Down / P-		Down
	Down / P-		Ch -
	Text		Text
	Input		AV
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text Cancel		Stop
	Text Reveal		Play





Original	Replacement	Original	Replacement
 Text Timer	 >>		
 Text Up	 >>		
 Text Index	 <<		
 Text Size	 REC MODE		
 Text Hold			
 Text Down	  <<		

