







































































| Original  |       | Replacement   |                    | Original  |         | Replacement   |                       |
|---|-------|---|--------------------|---|---------|---|-----------------------|
|    | Power |    | Power              |    | CH.List |    | Smart / List          |
|    | Info  |    | Info / Angle       |    | [=]     |    | D.Menu / Top          |
|    | Input |    | AV / Input / RDS   |    | Up      |    | Up                    |
|    | [++]  |    | Setup / OPT /      |    | Colors  |    | Fav / Marker / PC     |
|    | [/]1  |    | Picture / Format   |    | Left    |    | Left                  |
|    | [/]2  |    | Zoom / Size        |    | OK      |    | OK                    |
|    | 1     |    | 1                  |    | Right   |    | Right                 |
|    | 2     |    | 2                  |    | Back    |    | Back / Return         |
|    | 3     |    | 3                  |    | Down    |    | Down                  |
|   | 4     |   | 4                  |   | Play    |   | Play / Slow           |
|  | 5     |  | 5                  |  | Pause   |  | Pause / Step / Freeze |
|  | 6     |  | 6                  |  | Vol+    |  | Vol+                  |
|  | 7     |  | 7                  |  | Home    |  | Menu / Home           |
|  | 8     |  | 8                  |  | CH+     |  | CH+ / Page+           |
|  | 9     |  | 9                  |  | Vol-    |  | Vol-                  |
|  | Guide |  | Guide / EPG / -/-- |  | Mute    |  | Mute / Dimmer         |
|  | 0     |  | 0                  |  | CH-     |  | CH- / Page-           |



