



Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 Red	 Red / Netflix / Search
 Green / Aspect	 Green / APP / Repeat
 Green / Aspect	 Picture / Format
 Yellow	 Yellow / YouTube / Repeat
 Blue / SUBT	 Subtitle / EQ
 Blue / SUBT	 Blue / Prime Video / Random
 <<	 << / Tune-
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 USB	 Shift + 8
 Play / Pause	 Play / Slow
 Play / Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Rec	 Rec / Rec Mode

Original	Replacement
 F1 / Find	 D.Menu / Top
 F2 / Zoom	 Zoom / Size
 F2 / Zoom	 Setup / OPT /
 F3 / TXT	 Smart / List
 F3 / TXT	 Text / Goto
 F4	 Display / Media
 Menu	 Menu / Home
 Up / CH+	 Up
 Info	 Info / Angle
 Left / Vol-	 Left
 OK	 OK
 Right / Vol+	 Right
 FAV	 Fav / Marker / PC
 Down / CH-	 Down
 Exit	 Exit / Cancel / Clear
 Vol+	 Vol+
 EPG	 Guide / EPG / -/-





Original	Replacement	Original	Replacement
Pag+	CH+ / Page+		
Vol-	Vol-		
Audio	Audio / Lang I/II		
Pag-	CH- / Page-		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
Recall	Back / Return		
0	0		
TV / Radio	TV/Radio /		

Original	Replacement





Original		Replacement		Original		Replacement	
	Power		Power		F1 / Find		D.Menu / Top
	Mute		Mute / Dimmer		F2 / Zoom		Setup / OPT /
	Red		Red / Netflix / Search		F2 / Zoom		Zoom / Size
	Green / Aspect		Picture / Format		F3 / TXT		Text / Goto
	Green / Aspect		Green / APP / Repeat		F3 / TXT		Smart / List
	Yellow		Yellow / YouTube / Repeat		F4		Display / Media
	Blue / SUBT		Subtitle / EQ		Menu		Menu / Home
	Blue / SUBT		Blue / Prime Video / Random		Up / CH+		Up
	<<		<< / Tune-		Info		Info / Angle
	>>		>> / Tune+		Left / Vol-		Left
	I<<		I<< / Preset-		OK		OK
	>>I		>>I / Preset+		Right / Vol+		Right
	USB		Shift + 8		FAV		Fav / Marker / PC
	Play / Pause		Play / Slow		Down / CH-		Down
	Play / Pause		Pause / Step / Freeze		Exit		Exit / Cancel / Clear
	Stop		Stop / Hold		Vol+		Vol+
	Rec		Rec / Rec Mode		EPG		Guide / EPG / -/-





Original	Replacement
Pag+	CH+ / Page+
Vol-	Vol-
Audio	Audio / Lang I/II
Pag-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Recall	Back / Return
0	0
TV / Radio	TV/Radio /

Original	Replacement

