






















































Original	Replacement
 Standby	 Power
 TV/STB	 AV / Input / RDS
 Mute	 Mute / Dimmer
 F.List	 Display / Media
 Repeat	 Shift + Green / APP / REPEAT
 Res.	 Shift + Picture / Format
 Picture	 Picture / Format
 Book	 Shift + Smart / List
 Next Page	 Shift + Display / Media
 R.Skip	 I<< / Preset-
 REW	 << / Tune-
 FWD	 >> / Tune+
 F.Skip	 >>I / Preset+
 Rec	 Rec / Rec Mode
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze

Original	Replacement
 Menu	 Menu / Home
 Exit	 Exit / Cancel / Clear
 CH/PG+	 CH+ / Page+
 CH/PG-	 CH- / Page-
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Vol+	 Vol+
 Vol-	 Vol-
 Info	 Info / Angle
 EPG	 Guide / EPG / -/-
 Back	 Back / Return
 FAV	 Fav / Marker / PC
 SAT List	 Smart / List
 Option	 Setup / OPT /





Original	Replacement	Original	Replacement
 TV/Radio	 TV/Radio /	 7	 7
 Zoom	 Zoom / Size	 8	 8
 F1	 +  Shift + 1	 9	 9
 Red / Audio	 Red / Netflix / Search	 0	 0
 Red / Audio	 Audio / Lang I/II		
 Green / Subt	 Subtitle / EQ		
 Yellow / Text	 Yellow / YouTube / Repeat		
 Green / Subt	 Green / APP / Repeat		
 Yellow / Text	 Text / Goto		
 Blue / Sleep	 Blue / Prime Video / Random		
 Blue / Sleep	 Sleep / Timer		
 1	 1		
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		

Original	Replacement	Original	Replacement
 7	 7		
 8	 8		
 9	 9		
 0	 0		

