
































































Original		Replacement		Original		Replacement	
	Power On		Power		Up		Up
	Power Off	+	Shift + Power		Down		Down
	Device On	+	Shift + Pre Ch		Right		Right
	Device Off	+	Shift + 0		Left		Left
	Quick Select		Red		Enter		Ok
	Quick Select 2 / (SAT/CBL)		Green		<</Band		<<
	Quick Select 3/(Dock)		Yellow		Play		Play
	CH+		Ch +		>>/Mode		>>
	CH-		Ch -		I<</Tuning		I<<
	Vol+		Vol +		Pause		Pause
	Vol-		Vol -		Stop		Stop
	Mute		Mute		>>I/Tuning Up		>>I
	Source Select		AV		MulteQ		Dual
	Menu		Menu		DYN EQ		Media
	CH Level/Top	+	Shift + Menu		DYN Vol		Subt
	Search/Setup		Options		Restorer		Exit
	Return		Back		Standard		Text





Original	Replacement	Original	Replacement
 D/ST	 Format	 Power Tv	 TV/R
 Simulation	 3D	 Input Tv	 Shift + AV
 Input Mode	 Info	 Tv	 Shift + 1
 1	 1	 iPod	 Shift + 2
 2	 2	 DVD	 Shift + 3
 3	 3	 BD	 Shift + 4
 4	 4	 Tuner	 Shift + 5
 5	 5	 Dock	 Shift + 6
 6	 6	 SAT TU	 Shift + 7
 7	 7	 SAT/CBL	 Shift + 8
 8	 8	 Game	 Shift + 9
 9	 9	 V.AUX	 Shift + Guide
 0	 0		
 +10/Memory	 Guide		
 Shift/Link Menu	 Pre Ch		
 V.Sel	 Rec		
 Sleep	 Sleep		

Original	Replacement	Original	Replacement
 Power Tv	 TV/R	 Power Tv	 TV/R
 Input Tv	 Shift + AV	 Input Tv	 Shift + AV
 Tv	 Shift + 1	 Tv	 Shift + 1
 iPod	 Shift + 2	 iPod	 Shift + 2
 DVD	 Shift + 3	 DVD	 Shift + 3
 BD	 Shift + 4	 BD	 Shift + 4
 Tuner	 Shift + 5	 Tuner	 Shift + 5
 Dock	 Shift + 6	 Dock	 Shift + 6
 SAT TU	 Shift + 7	 SAT TU	 Shift + 7
 SAT/CBL	 Shift + 8	 SAT/CBL	 Shift + 8
 Game	 Shift + 9	 Game	 Shift + 9
 V.AUX	 Shift + Guide	 V.AUX	 Shift + Guide

