











Original	Replacement
Power	Power
Mute	Mute
PC	Media
Comp / HDMI	Smart
AV	AV
DTV / TV	Shift + TV/R
P.Mode	Shift + Format
S.Mode	Shift + Dual
Aspect	Format
Source	Shift + AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Original	Replacement
8	8
9	9
0	0
Still	Pause
Sleep	Sleep
Menu	Menu
Exit	Exit
Up	Up
Left	Left
OK	Ok
Right	Right
Down	Down
TTX	Text
Vol+	Vol +
Vol-	Vol -
i / Status	Info
PR+	Ch +





Original	Replacement	Original	Replacement
 PR-	 Ch -	 Guide	 Guide
 PIP	 Shift + Red	 Subtitle	 Subt
 P.Source	 Shift + Green	 I/II	 Dual
 P.Size	 Shift + Yellow	 Profile	 Pre Ch
 P.Sound	 Shift + Blue	 Audio	 Options
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Index	 Shift + Info		
 Cancel	 Back		
 Hold	 Stop		
 Subpage	 Shift + Subt		
 Reveal	 List		
 Mode	 Shift + Text		
 Store	 3D		
 TV / Radio	 TV/R		

Original	Replacement	Original	Replacement
 Guide	 Guide		
 Subtitle	 Subt		
 I/II	 Dual		
 Profile	 Pre Ch		
 Audio	 Options		

